



Wi-Fi 6 Router Side Label

- On the side of the device in which the wall mount holes are located is the EX3510's side label.
- This label displays the unit's default Wi-Fi Network Name (SSID) and the Wi-Fi Password.
- *The EX3510 uses one Wi-Fi Network Name (SSID) for both the 5G and 2.4G with Multy Pro enabled by default.*
- The default Administrator Username and Password are also displayed on the side label.



To Change Your Password

- Type 192.168.1.1 directly into your computer's web browser. Do not type it into a search engine.
- You will then be presented with a login screen to type in the default Username and Password.
- The default Username and Password are:
admin / <admin password> (as printed on the side label)
- You can then customize your Username and Password to those of your choice. If you have any questions, don't hesitate to call us at 800-422-4848!

A gray rectangular box representing a login screen. At the top center, the word "Login" is written in a bold, black, sans-serif font. Below this, there are two white input fields. The first field is labeled "User Name" in a small, gray font above it. The second field is labeled "Password" in a small, gray font above it. To the right of the password field is a small, gray eye icon. At the bottom center of the box, the word "Login" is written in a bold, black, sans-serif font.